

1 Q. Please identify the splices required on each of the cables crossing the SOBI.

2

3

4 A. Transition joints will be made between the submarine (landfall) and land cables at
5 each shore site, giving six in total. Additional submarine joints (one per cable for a
6 total of three) may be made as part of the cable pull into the Horizontal Directional
7 Drilling boreholes. The requirement for the submarine joints will be established
8 prior to cable installation.