

Q. Please provide a list of materials storage sites in each of Newfoundland Power's operating areas.

A. Newfoundland Power operates its main stores warehouse at the Duffy Place regional facility in St. John's. From the Duffy Place warehouse, materials are distributed to the stores warehouses in each of the operating area offices. Smaller inventories of materials are also maintained in the district buildings.

In addition to the stores warehouses, spare equipment is stored at the Electrical Maintenance Centre on Topsail Road in St. John's.

Table 1 lists the materials storage sites by region.

**Table 1:
Materials Storage Sites**

St. John's Region	Eastern Region	Western Region
<ul style="list-style-type: none"> • Duffy Place <ul style="list-style-type: none"> ○ Bell Island ○ Mobile 	<ul style="list-style-type: none"> • Carbonear <ul style="list-style-type: none"> ○ Whitbourne ○ Trepassey ○ Dunville • Clarenville <ul style="list-style-type: none"> ○ Port Union • Salt Pond Burin <ul style="list-style-type: none"> ○ Grand Bank ○ Bay L'Argent 	<ul style="list-style-type: none"> • Gander <ul style="list-style-type: none"> ○ Glovertown ○ New-Wes-Valley • Grand Falls-Windsor <ul style="list-style-type: none"> ○ Lewisporte ○ Summerford ○ Twillingate ○ Springdale ○ Baie Verte • Corner Brook <ul style="list-style-type: none"> ○ Deer Lake • Stephenville <ul style="list-style-type: none"> ○ Port Aux Basques